

INS12338A - 6/01

MOEN[®] 摩恩

Air-In Handheld Shower




PLEASE CONTACT MOEN FIRST For Installation Help, Missing or Replacement Parts (China) 400-630-8866 www.moen.cn

©2023 Moen Incorporated

Installation Instructions

- 1. Put the gasket ① (prepared by the user) into the connector of the hose ③ (prepared by the user).
- Tighten the hand shower ⁽²⁾ on the hose; connect the other end of the hose to the water source.



CAUTIONS:

MOEN[®]摩恩 Bathroom products are made with superb technology to ensure high quality,beautiful and durable. Be careful when cleaning the product to avoid damage to the surface of the product. Please clean the surface of the product with water or neutral detergent, and then dry it with a soft towel;

Do not use chemical or corrosive cleaners or rough cloths.

It is recommended to clean the product regularly to ensure its appearance is bright and clean.When using acidic cleaners to clean nearby items, it may damage the surface of the product.Please be extra careful.

Function Features

- Spray
- Hard Massage
- Spray Massage

This button can cycle through three different water outlet modes

Product Characteristics

Moen Air-in water breathing technology. The water flow is strong and soft, and colleagues who save 30% of water resources improve the comfort of the shower. Advanced button switching, you can easily switch the water outlet mode with one hand, leading the fashion trend. The front is complete and seamless, distinctive, and the appearance is more concise and generous.

- Strong and soft, environmentally friendly and water-saving.
- The product is beautiful and generous in appearance.
- The cover is large and there are many water outlets.
- The flow is large and the splash is evenly distributed.

MOEN LIMITED WARRANTY

We offer limited warranty and lifetime maintenance for Moen products, which are all manufactured with high standards of workmanship.

The period of warranty shall start from the date of purchase of the product (according to the invoice or receipt issued by Moen distributors) and shall cover a period of the following: the warranty period for shower is 1 year.


This warranty is your coverage against material and workmanship malfunction or defects in Moen products or components. During the warranty period, we offer free main tenance and changing of malfunctioned products or product components. Moen's after sales service liability is limited to the maintenance of faulty items and does not cover your other losses caused by product malfunction, except for other wise stipulated by law.

Cosmetic damages (scratches, dents, etc.) and malfunction or defects caused by abuse or improper maintenance is not covered by this warranty. Although the warranty period remains valid, in case of the following conditions (1) - (5), the maintenance cost [material cost and labor cost] shall still be charged as the case may be:

1.Corresponding warranty card and valid invoice cannot be presented;

2.Faults were caused by the incompliance with the instructions and precautions provided in the user's manual;

Dimensions



3.Damages and faults were caused by self-actuated dismantling, repair and refit;

4.Faults and damages were caused by external factors such as force majeure;

5.Damages were caused by transportation, unloading and extrusion, etc.

This warranty is valid for the original consumers only (including hotel use), and excludes industrial and commercial use of the product (except for hotel use). This card is only responsible for product maintenance rather than any other liabilities.

In the event that the product requires maintenance but exceeds the warranty period, or that the product is not covered by this warranty, labor cost and material cost shall be charged as the case may be.

Please call 400-630-8866 or contact local dealer for any question.



How to Clean the Nozzles: Any debris or mineral build-up may cause the

flow stream to become distorted or reduce the flowrate. To remove the debris or mineral build-up, run water through the handheld shower, and then press and rub the rubber water nozzles firmly.

How to Clean the Shower Body:

Cleaning Instructions

- Keep the product clean with clean water or mild liquid detergent regularly.
- Rinse it with clean water or mild liquid, and then dry it with soft cloth.
- Do not use acid or abrasive detergents.
- Do not clean the product with hard materials, for example, steel wool, scourer, etc.

The appearance of the Handheld Shower varies according to the different models. The figure above is for reference only.